

LP15 Standard Time/ Daylight Savings Time

Steps to change the time setting on the LP15:

Options

Date/Time

Change hour setting as needed

Exit

Turn LP15 off, then on to reset time